


RS232 connection



Note:
Pin 7 RTS and pin 8 CTS are
connected internally.


Note:
Powering a single instrument is not
possible by the D-sub connector.
Please consult 9.16.062 for a
connection diagram.

9 pin D-Sub
connector
chassis part
female

9 pin D-Sub
connector
cable part
male



RS232 COM -port
9 pin D-Sub
connector chassis
part male

Model key explanation




9 pin D-Sub
connector
chassis part
female

9 pin D-Sub
connector
chassis part
male




Note:
Do not connect an external valve to this connector.

Note:
1) +Valve out is 0...10Vdc 1mA.
2) For stand alone version: External power supply (+Us) = 24Vdc ±10%.



Analog operated
0...5 or 0...10Vdc



Analog operated
0...20 or 4...20mAdc

Note:
When using a field bus or RS232, it is not possible to operate the instrument by using the setpoint signal of the analog D-sub connector without changing the value of parameter "control mode". See doc.nr. 9.17.023 for more details.